

# Timpani Tuning Charts

## Suggested DrumDial, Lowest Timpani Settings

Timpani Size	DrumDial Setting
19" / 20"	78
23"	77
25" / 26"	76
29"	75
32"	74

### Common Ranges For Standard Timpani (Fifth)

20 Inch, From F3 to C4  
23 Inch, From D3 to A3  
26 Inch, From A2 to E3  
29 Inch, From F2 to C3  
32 Inch, From D2 to A2

### Common Ranges For Professional Timpani (Seventh)

20 Inch, From E3 to D4  
23 Inch, From C3 to B3  
26 Inch, From G2 to F3  
29 Inch, From E2 to D3  
32 Inch, From C2 to B3

### Extended Ranges For Professional Timpani (Octave)

20 Inch, From C3 to C4  
23 Inch, From B2 to B3  
26 Inch, From F2 to G3  
29 Inch, From D2 to E3  
32 Inch, From C2 to C3